Installation Instructions

- 1. Substrate must be dry and free of dust or any other "bond breaking" materials. La Crème Ornaments and trims are intended for use over the primary exterior weather barrier (i.e. wall system).
- 2. Refer to appropriate substrate detail for specific recommendations.
- EIFS detail A
- Masonry detail B
- Stucco/Cement Plaster detail C
- 3. Apply approved adhesive to back of La Crème Ornaments using 3/8" notched trowel. (Vertical pattern recommended)
- 4. While adhesive is wet, immediately install La Crème Ornaments and press into place. Remove excess adhesive before it dries.
- 5. Some pieces may require mechanical attachment until adhesive sets up. For temporary attachment use Zinc plated fasteners (or equal) with appropriate fastener may be used and then removed prior to the finish coat. For blind mechanical attachment into masonry, a stub nail driven into the surface will serve as a temporary hold until the adhesive cures. For blind attachment into EIFS, use a stub nail driven into the surface will serve as a temporary hold until the adhesive cures or a mechanical Zinc plated fastener.
- 6. Pieces can be joined using either a miter or straight cut. Check alignment of joints for proper fit prior to installation.
- 7. Prior to applying finish, ensure that:
- 1. All components are completely adhered and fully cured
- 2. All temporary fasteners are removed.
- 3. All joints have been treated and sanded flush.
- 4. All La Crème Ornament surfaces are clean and free of dirt, dust and other contaminants.

EIFS Detail "A"

MASONRY Detail "B"

STUCCO Detail "C"

La Crème Exterior Ornaments are intended for use as ornamental and aesthetic trims, and NOT as a primary weather barrier. *Flashing and caulking are necessary to prevent moisture intrusion at windows, doors and other penetrations, behind and below La Crème Exterior Ornaments. Installation of La Crème Exterior Ornaments should be done in coordination with appropriate flashings and should not interfere with the proper function of windows, doors, weep holes, etc. CALL LA CRÈME EXTERIOR ORNAMENTS FOR JOB SPECIFIC ASSISTANCE. 1-888-761-7404